

3M Mount

TRP1423/ TRP1708



TRP1423



TRP1708



Make sure the surface
is clean and smooth



Peel off the paper
on the back



Put it on the right position
Press to let the air out
Wait for 24H before use